

# Graveley Lab shRNA knockdown followed by RNA-seq Library Preparation and Characterization Document

**Wet Lab:** Sara Olson and Lijun Zhan  
**Computational Lab:** Xintao Wei and Michael Duff  
**PI:** Brenton Graveley

Department of Genetics and Genome Sciences  
UConn Institute for Systems Genomics  
UConn Health  
400 Farmington Avenue  
Farmington, CT 06030 USA

December 7, 2017

**Project:** ENCODE3  
**Grant:** U54HG007005  
**Sample Description:** shRNA Knockdown of IGF2BP3 in K562 cells  
**Cell Line:** K562  
**RNA ID:** K-IGF2BP3-25B-1  
**Multiplex Barcode:** ACAGTG  
**ENCODE BIOSAMPLE ACCESSION:** ENCBS159KYP  
**ENCODE LIBRARY ACCESSION:** ENCLB297UKH  
**ENCODE EXPERIMENT ACCESSION:** ENCSR481YXD

This document contains the protocols used for library preparation and characterization of RNA isolated from K562 cells depleted of IGF2BP3.

## RNA Quality Control

RNA was isolated from K562 cells transfection with an shRNA targeting the IGF2BP3 mRNA as described in ENCODE Biosample Accession number ENCBS159KYP. The quality of the RNA was measured using an Agilent TapeStation Instrument with an RNA Screen Tape (Catlog Number 5067–5576).

1. Mix 1  $\mu\text{l}$  of RNA and 5  $\mu\text{l}$  RNA sample buffer.
2. Vortex and briefly spin to ensure sample is at the bottom of the tube.
3. Heat samples in a thermocycler to 72 °C for 3 minutes.
4. Place samples on ice, then briefly spin to ensure sample is at the bottom of the tube.
5. Run samples on the RNA Screen Tape.




Figure 1: Agilent TapeStation image of 1  $\mu\text{l}$  of the input total RNA sample.

## Library Prep Protocol

RNA-Seq libraries were prepared following the Illumina the TruSeq Stranded Total RNA Sample Preparation Kit (Catalog numbers RS–122–2201 or RS–122–2202). Spike-in RNAs are obtained from NIH (Catalog number ERCC–78A–11119).

### RiboZero Deplete and Fragment RNA

This process depletes ribosomal RNA from total RNA. After the ribosomal RNA is depleted, the remaining RNA is purified, fragmented and primed for cDNA synthesis.

1. Dilute 1.0  $\mu\text{g}$  of the total RNA with nuclease-free ultra pure water to a final volume of 5  $\mu\text{L}$  in a 0.3 ml PCR plate or tube with a 1:1000 ratio of spike-ins.

2. Add 2.5  $\mu$ l of rRNA Binding Buffer to each sample well.
3. Add 2.5  $\mu$ l of Ribo-Zero rRNA Removal Mix to each sample well.
4. Gently pipette the entire volume up and down 6 times to mix thoroughly.
5. Seal the plate with a Microseal 'B' adhesive seal.
6. Incubate the sample in a thermal cycler at 65 °C for 5 minutes to denature the RNA and facilitate binding of the RNA to the rRNA Removal Mix.
7. After the 5-minute incubation, incubate the sample at room temperature for 1 minute to allow the rRNA to bind to the rRNA Removal Mix.
8. Vortex the rRNA Removal Beads vigorously to completely resuspend the beads.
9. Add 17.5  $\mu$ l of rRNA Removal Beads to each sample and quickly pipette up and down 20 times to mix thoroughly.
10. Incubate at room temperature for 1 minute, and then place on the magnetic stand for 1 minute to separate the rRNA bound to the beads from the solution.
11. Transfer all of the supernatant to a new well. If there are carryover magnetic particles, incubate on the magnetic stand 1 minute and transfer all of the supernatant to a new well.
12. Vortex the RNAClean XP beads until they are well dispersed and add 49.5  $\mu$ l of the vortexed beads to each sample containing rRNA depleted RNA. Gently pipette up and down 10 times to mix.
13. Incubate the sample at room temperature for 15 minutes.
14. Place the sample on the magnetic stand at room temperature for 5 minutes, until all the beads are bound to the side of the wells.
15. Remove and discard all of the supernatant from each well.
16. Keeping the samples on the magnetic stand, add 100  $\mu$ l of freshly prepared 70% EtOH to each sample without disturbing the beads.
17. Incubate at room temperature for 30 seconds, then remove and discard all of the supernatant from each sample.
18. Let the plate stand at room temperature for 5 minutes to dry the beads, then remove from the magnetic stand.
19. Add 6.5  $\mu$ l Elution Buffer to each sample and pipette up and down 10 times to mix thoroughly.
20. Incubate the plate at room temperature for 2 minutes.
21. Quickly spin the plate for 30 seconds if the sample is not at the bottom of the well, and then place on the magnetic stand for 5 minutes.
22. Transfer 4.25  $\mu$ l of the supernatant to a new well.

23. Add 4.25  $\mu\text{l}$  Elute, Prime, Fragment High Mix to each sample and gently pipette up and down 10 times to mix.
24. Seal the plate and incubate in a thermal cycler at 94°C for 4 minutes, then hold at 4°C to elute, fragment and prime the RNA.
25. Remove the sample from the thermal cycler and centrifuge briefly.

### **Synthesize First Strand cDNA**

This process reverse transcribes the cleaved RNA fragments that were primed with random hexamers into first strand cDNA using reverse transcriptase and random primers. The addition of Actinomycin D to the First Strand Synthesis Act D mix prevents spurious DNA-dependent synthesis, while allowing RNA-dependent synthesis, improving strand specificity.

1. Place the sample on the magnetic stand at room temperature for 5 minutes.
2. Transfer 8.5  $\mu\text{l}$  of the supernatant to a new 0.3 ml plate or tube.
3. Add SuperScript II to the First Strand Synthesis Act D Mix tube at a ratio of 1  $\mu\text{l}$  SuperScript II for each 9  $\mu\text{l}$  First Strand Synthesis Act D Mix.
4. Add 4.0  $\mu\text{l}$  of First Strand Synthesis Act D Mix and SuperScript II mix to the sample and gently pipette the entire volume up and down 6 times to mix thoroughly.
5. Place the sample in a thermal cycler and incubate at 25°C for 10 min, 42°C for 15 min, 70°C for 15 min, and hold at 4°C.
6. Remove the sample from the thermal cycler and proceed immediately to the second strand cDNA synthesis reaction.

### **Synthesize Second Strand cDNA**

This process removes the RNA template and synthesizes a replacement strand, incorporating dUTP in place of dTTP to generate ds cDNA. The incorporation of dUTP quenches the second strand during amplification, because the polymerase does not incorporate past this nucleotide.

1. Add 2.5  $\mu\text{l}$  of Resuspension Buffer to the reaction.
2. Add 10  $\mu\text{l}$  of thawed Second Strand Marking Master Mix to the reaction.
3. Gently pipette the entire volume up and down 6 times to mix thoroughly.
4. Return the reaction to the pre-heated thermal cycler, close the lid and incubate at 16°C for 1 hour.
5. Remove the reaction from the thermal cycler, place it on the bench and let it to come to room temperature.

6. Add 45  $\mu\text{l}$  of well-mixed AMPure XP beads (Beckman Coulter, Catalog Number A63881) to the ds cDNA.
7. Gently pipette the entire volume up and down 10 times to mix thoroughly and incubate at room temperature for 15 minutes.
8. Place the reaction on the magnetic stand at room temperature, for 5 minutes to make sure that all of the beads are bound to the side of the wells.
9. Remove and discard 65.0  $\mu\text{l}$  of supernatant from the reaction.
10. While leaving the tube on the magnetic stand add 150  $\mu\text{l}$  freshly prepared 80% EtOH without disturbing the beads.
11. Incubate at room temperature for 30 seconds, and then remove and discard all of the supernatant.
12. Repeat once for a total of two 80% EtOH washes.
13. Let stand at room temperature for 15 minutes to dry, and then remove from the magnetic stand.
14. Add 11.25  $\mu\text{l}$  Resuspension Buffer and gently pipette the entire volume up and down 10 times to mix thoroughly.
15. Incubate at room temperature for 2 minutes and then place on the magnetic stand at room temperature for 5 minutes.
16. Transfer 8.75  $\mu\text{l}$  supernatant (ds cDNA) from the tube to the new 0.3 ml PCR plate or tube.

## A Tailing

A single 'A' nucleotide is added to the 3' ends of the blunt fragments to prevent them from ligating to one another during the adapter ligation reaction. A corresponding single 'T' nucleotide on the 3' end of the adapter provides a complementary overhang for ligating the adapter to the fragment. This strategy ensures a low rate of chimera (concatenated template) formation.

1. Add 6.25  $\mu\text{l}$  of thawed A-Tailing Mix to each reaction.
2. Gently pipette the entire volume up and down 10 times to mix thoroughly.
3. Gently pipette the entire volume up and down 10 times to mix thoroughly.
4. Place the tube in a thermal cycler with the lid pre-heated to 100 °C, close the lid, and incubate at 37 °C for 30 minutes, 70 °C for 5 minutes, and hold at 4 °C.
5. Proceed directly to ligating the adapters.

## Ligate Adapters

This process ligates multiple indexing adapters to the ends of the ds cDNA, preparing them for hybridization onto a flow cell.

1. Add 1.25  $\mu$ l of Resuspension Buffer to each reaction.
2. Add 1.25  $\mu$ l of Ligation Mix to each reaction.
3. Add 1.25  $\mu$ l of the thawed RNA Adapter Index to each reaction.
4. Gently pipette the entire volume up and down 10 times to mix thoroughly.
5. Place the tube in the pre-heated thermal cycler. Close the lid and incubate at 30°C for 10 minutes.
6. Remove from the thermal cycler.
7. Add 2.5  $\mu$ l of Stop Ligation Buffer to each reaction to inactivate the ligation.
8. Gently pipette the entire volume up and down 10 times to mix thoroughly.
9. Vortex the AMPure XP Beads for at least 1 minute or until they are well dispersed.
10. Add 21  $\mu$ l of mixed AMPure XP Beads to each reaction.
11. Gently pipette the entire volume up and down 10 times to mix thoroughly.
12. Incubate the ALP plate at room temperature for 15 minutes.
13. Place the ALP plate on the magnetic stand at room temperature for 5 minutes or until the liquid is clear.
14. Remove and discard 38.0  $\mu$ l of supernatant from the tube taking care not to disturb the beads.
15. With the tube on the magnetic stand, add 150  $\mu$ l freshly prepared 80% EtOH without disturbing the beads.
16. Incubate at room temperature for 30 seconds, and then remove and discard all of the supernatant taking care not to disturb the beads.
17. Repeat twice for a total of two 80% EtOH washes.
18. While still on the magnetic stand, let the samples air-dry at room temperature for 15 minutes.
19. Remove the tube from the magnetic stand.
20. Add 27.5  $\mu$ l Resuspension Buffer to each tube.
21. Gently pipette the entire volume up and down 10 times to mix thoroughly or until the beads are fully resuspended.
22. Incubate at room temperature for 2 minutes.

23. Place the reaction on the magnetic stand at room temperature for 5 minutes or until the liquid is clear.
24. Transfer 25  $\mu\text{l}$  of supernatant from the tube to a new 0.3 ml PCR plate or tube labeled with the CAP barcode. Take care not to disturb the beads.
25. Vortex the AMPure XP Beads until they are well dispersed.
26. Add 25  $\mu\text{l}$  of mixed AMPure XP Beads to each tube for a second cleanup.
27. Gently pipette the entire volume up and down 10 times to mix thoroughly.
28. Incubate at room temperature for 15 minutes.
29. Place the tube on the magnetic stand at room temperature for 5 minutes or until the liquid is clear.
30. Remove and discard 47.5  $\mu\text{l}$  of supernatant taking care not to disturb the beads.
31. With the tube on the magnetic stand, add 150  $\mu\text{l}$  freshly prepared 80% EtOH taking care not to disturb the beads.
32. Incubate at room temperature for 30 seconds, and then remove and discard all of the supernatant taking care not to disturb the beads.
33. Repeat one time for a total of two 80% EtOH washes.
34. With the tube on the magnetic stand, let the sample air-dry at room temperature for 15 minutes, and then remove the tube from the magnetic stand.
35. Add 12.5  $\mu\text{l}$  Resuspension Buffer to the tube.
36. Gently pipette the entire volume up and down 10 times to mix thoroughly or until the beads are fully resuspended.
37. Incubate at room temperature for 2 minutes.
38. Place the tube on the magnetic stand at room temperature for 5 minutes or until the liquid is clear.
39. Transfer 10  $\mu\text{l}$  of supernatant to a new 0.3 ml PCR plate or tube taking care not to disturb the beads.

## **Enrich DNA Fragments**

This process uses PCR to selectively enrich those DNA fragments that have adapter molecules on both ends and to amplify the amount of DNA in the library. The PCR is performed with a PCR Primer Cocktail that anneals to the ends of the adapters. Minimize the number of PCR cycles to avoid skewing the representation of the library.

1. Add 2.5  $\mu\text{l}$  of thawed PCR Primer Cocktail to the sample.
2. Add 12.5  $\mu\text{l}$  of thawed PCR Master Mix to the sample.

3. Gently pipette the entire volume up and down 10 times to mix thoroughly.
4. Place the tube in the pre-programmed thermal cycler with the lid pre-heated to 100 °C, close the lid, and incubate at 98 °C for 30 seconds, and then 15 cycles of 98 °C for 10 seconds, 60 °C for 30 seconds, 72 °C for 30 seconds, and then 72 °C for 5 minutes and hold at 4 °C.
5. Add 25  $\mu$ l of AMPure XP Beads to the tube.
6. Gently pipette the entire volume up and down 10 times to mix thoroughly.
7. Incubate the PCR plate at room temperature for 15 minutes.
8. Place the tube on a magnetic stand at room temperature for 5 minutes or until the liquid is clear.
9. Remove and discard 47.5  $\mu$ l of supernatant from the tube.
10. While on the magnetic stand, add 150  $\mu$ l freshly prepared 80% EtOH without disturbing the beads.
11. Incubate at room temperature for 30 seconds, and then remove and discard all of the supernatant.
12. Repeat one time for a total of two 80% EtOH washes.
13. While on the magnetic stand, let the sample air-dry at room temperature for 15 minutes, and then remove from the magnetic stand.
14. Add 27.5  $\mu$ l Resuspension Buffer to the sample.
15. Gently pipette the entire volume up and down 10 times to mix thoroughly.
16. Incubate at room temperature for 2 minutes.
17. Place the sample on the magnetic stand at room temperature for 5 minutes or until the liquid is clear.
18. Transfer 25  $\mu$ l of the supernatant from the tube to a new 0.3 ml PCR plate or tube.

## **Validate Library**

1. Initially quantitate the libraries by Nanodrop or Tecan.
2. Further validate the libraries by running on an Agilent TapeStation D1000 screen tape (Catalog number 5067–5582). Dilute 1  $\mu$ l of each library into 3  $\mu$ l of sample buffer and run on the TapeStation.






Figure 2: Agilent TapeStation image of 1  $\mu$ l of the library.